



## ROTO




1. Switch-off the power supply before any installation and maintenance operations
2. Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
3. Connect this lighting according to voltage and frequencies mention on driver


1. Isključite napajanje prije svake instalacije i održavanja
2. Instalaciju treba izvesti odgovarajuće kvalificirana osoba u skladu s dobrom električnom praksom i odgovarajućim nacionalnim propisima ožičenja.
3. Spojite ovu rasvjetu prema naponu i frekvenciji navedenim na napajanju




1. Cut off the AC power, use the junction box to locate the screw hole on the ceiling.




2. Insert the screw sleeve into the fixing hole.




3. Fixing the junction box to the ceiling.




4. Connect the wiring terminals.



5. Connect the safety rope and PCB & driver cables.






6. Push the light fixture upward to align it with the junction box, then rotate the light fixture to lock it in place. Refer to steps A and B for details.




7. Turn on the light and check if working properly.


### Install the wiring




### Parts included



1PCS



3PCS



3PCS